



- *1 REMARK for PS-140II
- WITHOUT OVERVOLTAGE FUNCTION,
- WITHOUT METER INDICATI & VOLTAGE ADJUST FUNC NO CONTENTS: VR1, S2, METER, RV3, R21, R22, R23, and R8.

*1 PS-140 I3
(VR1, S2, METER)
(RV3, R24, R22, R23, R8)

*2 R16 ADJ at 14A
R21 ADJ at Meter scale

OVER VOLTAGE PROTECTOR